


























Before (last saved 2018-10-09)

	<b>Power on/off key:</b> Press to turn the indicator on. To turn it off, press and hold the button for a few seconds.
	<b>+ key:</b> The most frequent used function key. Press to use the programmed function. (See 6.8.7 + Function Key Usage)
	<b>Sampling key:</b> Press and hold the key for a few seconds to start sampling in piece counting. (See 6.3.1 Sampling)
	<b>Escape key:</b> In menu mode, press this key to escape from menu and return to normal mode. Parameters are not saved.
	<b>Tare key:</b> Press this key to deduct the weight of the container placed on the platform so as to see the net weight value of the material subsequently added into or taken out of the container. (See 6.2.2 Taring)
	<b>Check weighing key(H-L):</b> To enter check weighing operation press this key until the [H-L : n] message appears. (See 6.4 CHECK WEIGHING)
	<b>Zero key:</b> This key adjusts the scale zero, if there is any residual weight or drift. Zeroing should be done without any load on the platform. (See 6.2.1 Zeroing)
	<b>f key:</b> During normal weighing press to use the programmed function. (See 6.8.8 f Function Key Usage)
	<b>ADV key:</b> This key is used to enter advance function setting by pressing and holding for a few seconds. (See 6.8 ADVANCED USER FUNCTIONS)
	<b>M+ Add to memory key:</b> Press this key to add the indicated weight to the accumulator in weighing and in counting operations. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>MR Memory read:</b> Press this key to show accumulated total weight in weighing operation or accumulated quantity in piece counting operation. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>MC Memory clear key:</b> Press this key to erase the accumulated value from memory. The weight and count accumulators will be erased separately. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>Enter key:</b> Press this key for printout or to move to the next item during configuration.
	<b>Navigation keys:</b> Navigation keys are located on the right of the indicator front which are up, down, left and right arrow keys. These keys are used for navigation in set up and to change any numerical value. RIGHT: Next menu item, select digit to the right. LEFT: Previous menu item, select digit to the left. UP: Increase the selected digit value. DOWN: Decrease the selected digit value.

After (7.1.4.2)

	<b>Power on/off key:</b> Press to turn the indicator on. To turn it off, press and hold the button for a few seconds.
	<b>+ key:</b> The most frequent used function key. Press to use the programmed function. (See 6.8.7 + Function Key Usage)
	<b>Sampling key:</b> Press and hold the key for a few seconds to start sampling in piece counting. (See 6.3.1 Sampling)
	<b>Escape key:</b> In menu mode, press this key to escape from menu and return to normal mode. Parameters are not saved.
	<b>Tare key:</b> Press this key to deduct the weight of the container placed on the platform so as to see the net weight value of the material subsequently added into or taken out of the container. (See 6.2.2 Taring)
	<b>Check weighing key(H-L):</b> To enter check weighing operation press this key until the [H-L : n] message appears. (See 6.4 CHECK WEIGHING)
	<b>Zero key:</b> This key adjusts the scale zero, if there is any residual weight or drift. Zeroing should be done without any load on the platform. (See 6.2.1 Zeroing)
	<b>f key:</b> During normal weighing press to use the programmed function. (See 6.8.8 f Function Key Usage)
	<b>ADV key:</b> This key is used to enter advance function setting by pressing and holding for a few seconds. (See 6.8 ADVANCED USER FUNCTIONS)
	<b>M+ Add to memory key:</b> Press this key to add the indicated weight to the accumulator in weighing and in counting operations. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>MR Memory read:</b> Press this key to show accumulated total weight in weighing operation or accumulated quantity in piece counting operation. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>MC Memory clear key:</b> Press this key to erase the accumulated value from memory. The weight and count accumulators will be erased separately. (See 6.2.4 Weight Accumulation in weighing and 6.3.6 Piece count totalising in piece counting)
	<b>Enter key:</b> Press this key for printout or to move to the next item during configuration.
	<b>Navigation keys:</b> Navigation keys are located on the right of the indicator front which are up, down, left and right arrow keys. These keys are used for navigation in set up and to change any numerical value. RIGHT: Next menu item, select digit to the right. LEFT: Previous menu item, select digit to the left. UP: Increase the selected digit value. DOWN: Decrease the selected digit value.